

PureChannel™ Flush Touchless Auto Dispenser – Installation Guide

	<p>1. Pre-screw the thicker pegboard screws into the center drilled hole and bottom hole on the back panel of the pump. Align the pump to where you would like it installed on your pegboard. Secure the screws in place with the ends.</p>
	<p>2. Place the top control panel on the back panel. Using the longer, thinner screws in the hardware panel, pictured below. Screw the top control panel and back panel together.</p>
	<p>3. Seal the holes on the side of the top control panels with the blue seals found in the hardware bag, pictured right.</p>