



## GelPro® Anti-Fatigue Mat – Care and Cleaning Instructions

For in-hospital environments, GelPro Mats may be cleaned with a low-level hospital grade disinfectant cleaner which kills blood-borne pathogens. We recommend using Spec Clean™ Ready-to-Use Disinfectant and Cleaner or a cleaning agent similar in composition.

For cart washing, wash in plastic mode setting if your washer has this option. Use a low foaming detergent.

<b>Water Temp:</b>	147 F to 152°F
<b>Wash Duration:</b>	1 to 3 minutes
<b>Drying temperature:</b>	248°F to 253°F or Air Dry
<b>Drying duration:</b>	5 minutes

For non-hospital environments, clean with water and a damp sponge or cloth. If you have a sticky or greasy spill, you may use a mild soap (such as dish washing detergent) and water with a damp sponge or cloth.

**Do not** use any other household cleaners such as, but not limited to, window cleaners, floor cleaners, polishes or all purpose cleaners.

**Do not** clean with a power vacuum cleaner. The high speed rotating brush can damage the surface of the mat.

**Do not** fold the mat as this can cause permanent damage.

**Do not** place furniture or equipment on the GelPro Mat. Permanent indentations on mat may occur.

**Do not** allow water/liquid to become trapped under the GelPro Mat. If any moisture/liquid becomes trapped under a GelPro Medical Mat, it may not dry and, therefore, it should be removed as soon as possible.

When mopping your floor, please ensure that your floor has completely dried before replacing the mat. Prolonged exposure to moisture/liquid trapped under the GelPro Medical Mat may cause mold/mildew and/or damage to your mat and some types of flooring surfaces.

**Do not** use acetone, window cleaners, alcohol, bleach or ammonia to clean your mat. These cleaning agents will damage your mat and void your warranty.



### **Replace and Reuse Guidance**

GelPro Mats are a great solution for decontamination environments, the operating room, or other areas of your medical facility. With proper care and cleaning, they will provide lasting comfort & ergonomic support. It is recommended to replace your anti-fatigue mats on an annual basis, or as they become damaged or torn.