

VR™ Sleeve Gloves – Care and Maintenance

Donning

1. Grab the end of the elastic or plain glove cuff and begin gently pulling sleeve and glove onto hand.
2. When sleeve is pulled up to upper arm, start pulling gently on middle part of sleeve and then lower part of sleeve so that the hand enters the glove portion.
3. When fingers start to enter the finger portion of the glove, release the sleeve portion and start drawing down the glove and glove fingers so that your fingers fit snugly into the glove. Adjust sleeve portion to desired coverage and begin use.

Doffing

1. Slide or gently pull the sleeve portion down onto the middle forearm.
2. Begin pulling on glove fingers (one or more at a time) and thumb, to remove glove from hand.

Cleaning & Sanitizing

1. In-between trays or after final use of the day/shift, use detergent or other cleaning compound and wash the gloves while they are being worn (using one glove hand to wash the other).
2. Rinse the gloves while being worn and spray liberally with a sanitizing solution or quaternary ammonium disinfectant.
3. Remove as instructed above and hang or drape to dry for next use.

Recommendations for Cleaning

VR gloves can be laundered in a washing machine with warm water and a mild laundry detergent. **Do not attempt to dry the apparel in a clothes dryer** with heat. It's preferable that items are drip dried or inserted into a cool dryer using only ambient air without heat.

Based on the bio-load, all apparel can be hung and hosed down with a medium pressure, warm spray, then left to drip dry.

A low concentration chlorine dip (w/concentration changed out periodically) or rinse can be used for cleaning and disinfecting.

It is recommended that VR Gloves are replaced on a daily basis.